



secuENTRY pro

Electronic Door Lock
secuENTRY pro 7073 ENROLMENT

en Download: www.burg.biz
fr Download: www.burg.biz
nl Download: www.burg.biz
it Download: www.burg.biz
es Descarga: www.burg.biz
pt Download: www.burg.biz

se Download: www.burg.biz
no Download: www.burg.biz
dk Download: www.burg.biz
fi Ladattava tiedosto: www.burg.biz
el λήψη: www.burg.biz
tr İndir: www.burg.biz

ro Descărcare: www.burg.biz
pl Pobieranie pliku: www.burg.biz
cz Stáhnout: www.burg.biz
hu Letölthető: www.burg.biz
sl Download: www.burg.biz
sk Download: www.burg.biz

hr Download: www.burg.biz
ru загрузка: www.burg.biz
bg Download (зареди): www.burg.biz
et Download: www.burg.biz
BW_Enrolment_BA_sE_014111
kfs 06/2016



Instructions for use

Dear customer,
thank you for choosing the **secuENTRY pro 7073 ENROLMENT**.
With the help of the **secuENTRY pro 7073 ENROLMENT** you can save finger scans and transponders in the secuENTRY software.

Via the provided USB cable a connection between the **secuENTRY pro 7073 ENROLMENT** unit and the computer is established, a software for installation is not needed. You can find additional information in the user's manual of the secuENTRY software.

The following image shows the reading areas of the ENROLMENT unit:



- 1 RFID Reading area
- 2 Fingerprint sensor

III.1: Reading areas


Reading of transponders

Lay the transponder onto the RFID reading area of the **secuENTRY pro 7073 ENROLMENT** unit.



III.2: Reading-placement of the transponder

Via the user administration of the secuENTRY software, transponders are being registered with a right click in the "Serial Number" field, under "Learning-In" → "Transponder".




III.3: secuENTRY software

The serial number of the transponder is filled in automatically.

Reading of fingerprints

Via the user administration of the secuENTRY software, fingerprints are being read with a right click on the field "FS1" resp. "FS2" "Learning-In".



III.4: secuENTRY software

The software will guide you through the next steps. To register your fingerprint, you need to move your finger in direction of arrow over the sensor.



III.5: Direction of movement while reading the finger

Description of LED display

Placed in the upper range of the secuENTRY pro 7073 ENROLMENT unit there are two coloured LEDs.

- Green LED:** Readiness for a successful learning in.
- Green LED flashing:** Data transfer.
- Red LED:** Finger not accepted.

Warranty

To provide you with a qualitative impeccable and valuable product and to optimally help you in the case of service or repair, it is necessary that flawed or defective devices are handed back to your retailer together with the QR code-s and the original proof of purchase.

With returning according to your cancellation right, all components need to be in factory setting. In the case of a disregard, warranty expires.

Disposal of your device

Dear customer,

please help avoiding waste. If you consider to dispose of this device, please note that many components of it consist of valuable materials that can be recycled.



We point to the fact that electric and electronical devices as well as batteries are not to be disposed via household rubbish, but need to be collected separately. Please inform yourself at your local competent authority about respective collecting points for batteries and electric waste.



For questions about the EG declaration of conformity please contact info@burg.biz.

Printing and typographical errors as well as technical alterations reserved.